

CONFY CARE®


PRO series Treatment Table USER GUIDE



Scan this QR
to read in other
languages:
ES, FR, IT, DE

Contents

Electric Treatment Table	-----	P1 - 13
Hydraulic Treatment Table	-----	P14 - 24



**EL01PRO23 / EL11PRO23 / EL11ARPRO23 /
EL02PRO23 / EL022PRO23 / EL022ARPRO23 /
EL03PRO23 / EL03EPRO23 / EL032PRO23 /
EL04PRO23 / EL05PRO23 / EL05ARPRO23 / EL052PRO23**

Electric Treatment Table

USER GUIDE

SAFETY PRECAUTIONS

1. During the adjustment of the table, do not put any part of the body into the gap of any moving parts.
2. Please operate with both hands when adjusting the leaning angle of back, foot or head sections.
3. When the patient is on the table, it is not recommended to adjust the angle of the table top.
4. Before using the product, ensure the four feet of the table frame touch the ground at the same time and check the stability of the table frame.
5. Before connecting to the power supply, please check whether the incoming line to the controller is intact.
6. A regular inspection (at least once a year) is needed for the treatment table.
7. Do not exceed the table weight capacity of 250 kg. The safe working load of the armrest is 15 kg.
8. Always clean the table after each use with a soft cloth dampened with water and a mild antibacterial detergent. Do not use abrasive cleaners.
9. Disconnect the table from the power source before attempting any maintenance, installation, removal or replacement procedures to prevent electrical shock and possible damage to the table.
10. Please DO NOT make any changes to the table. Replacement parts or labor can be provided by CoinfyCare, the selling dealer or a service technician certified by the manufacturer.

CONTENTS OF CARTON

Electric Treatment Table: 1 unit
User Guide: 1 unit

NORMAL OPERATING CONDITIONS

Temperature: 0 °C - 40 °C
Relative humidity: 10% - 95%
Air pressure range: 860-1060hpa
Power supply: AC 100-240V, 50/60Hz

REGULATION AND PRODUCT STANDARDS

This table complies with the European regulation of medical devices (EU) 2017/745 and with the following standards:

- EN 60601-1:2006+A1:2013+AC:2014
Medical electrical equipment. Part 1: General Requirements for Basic Safety and Essential Performance.
- IEC/EN 60601-2-52:2009+A1:2015 clause 201.9.8.3.2
Medical electrical equipment. Part 2-52: Particular requirements for basic safety and essential operation of medical tables.
- EN 60601-1-6:2010+A1:2015
Medical electrical equipment. Part 1-6: General Requirements for basic safety and essential performance. Collateral standard: Possibility for use
- EN 60601-1-2:2015
Medical electrical equipment. Part 1-2: General requirements for basic safety and essential performance. Collateral standard: Electromagnetic disturbances. Requirements and tests.
- EN ISO 13485:2016
Medical devices - Quality management systems - Requirements for regulatory purposes (ISO 13485:2016)
DIN EN ISO 13485:2016

PRECAUTIONS AND SAFETY INDICATIONS

CoinfyCare is not liable for any material or personal damage due to misuse or incorrect use of this table or for any purpose other than described in this user guide.

Inspect the condition of the table before using it for the first time and on a recurring basis as indicated in the "MAINTENANCE" section.

Keep table out of high moisture environments.

Do not transport the table over rough or outdoor surfaces. The retractable caster system could become damaged and inoperable.

This table should be operated, transported, and stored in temperatures between -10° C to + 50° C, with max humidity of 95%.

DO NOT operate this table in an environment where other devices are being used that intentionally radiate electromagnetic energy in an unshielded manner. Portable and mobile communications equipment can affect Medical Electrical Equipment.

This table generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to other devices in the vicinity. However, there is no guarantee that interference will not occur in a particular installation. Harmful interference to other devices can be determined by turning this table on and off. Try to correct the interference using one or more of the following: reorient or relocate the receiving device, increase the separation between the equipment, connect the table to an outlet on a different circuit from that which the other device(s) are connected, and consult CoinfyCare or your local dealer for help.

Unplug the table from the power supply before starting cleaning or any type of maintenance operations.

The table should be kept out of the reach of children when there is no adult supervision.

The table is designed for discontinuous interval operation, so the continuous running time of the motor should never exceed 2 minutes. Should this happen, damage may occur due to overheating of the electronics.

Always use original accessories and spare parts provided by your local dealer.

Always cover the table with a towel, disposable paper or a cover and change it for each user, thus ensuring correct hygiene and extending the useful life of the upholstery.

Only connect the table to a properly installed and grounded outlet. The local mains voltage must correspond to the technical data of the device.

The power outlet should be accessible in case the table needs to be quickly unplugged at any given time. Always pull the plug and not the mains cable.

Unplug the table from the power supply before starting cleaning or any types of maintenance operations.

If the electrical supply cable is defective, disconnect the table immediately and inform your dealer or a specialized technician.

Position the power cord properly so that it cannot be tripped over.

Unplug the power cord from the mains if the table is not going to be used for a long period of time.

If you detect any abnormality in the operation of the table, consult your dealer or a specialized technician.

Never manipulate any electrical part or open or repair any part of the table.

Only your dealer or a specialized technician should repair the table.

Never touch the table or the power cord with wet hands.

Never place your hands or any other part of your body in any hole or void on the table while it is in operation.

Make sure there are no objects in the space under the table that could cause collisions or entrapment during operation.

Make sure that your feet are not resting on the peripheral foot bar or foot control during treatment and especially when sitting near the table. This could create a dangerous situation where your leg is caught between the section and the peripheral foot bar or floor surface.

Take into account the weight distribution on the table when working. The weight must be distributed along the table without concentrating on its ends to maintain the correct stability.

You should not sit on the head and foot sections. If you do, there is a danger of tipping and table damage.

PLACEMENT IN THE WORKPLACE

The table has four casters to facilitate movement to the place where it will be used.

To activate or deactivate this system, you must press either of the two levers with your foot, as shown in the following figures.

Figure 1: Table in working position.




Figure 1

Figure 2: Table in moving position.





Figure 2

OPERATION


Connect the bed to an electrical outlet using the power cord.

Motor functions

- Peripheral foot bar for height adjustment
 - Before adjusting, make sure there are no objects in the space below the table that could cause collisions or entrapment.
 - Press the peripheral foot bar with your foot to one side or the other side to adjust the height of the table.





- Foot switch for height adjustment
 - Use the foot switch to adjust the height of the table.




- Button control for adjusting the central / mid section

- There's a button on the right side of the table near backrest. Press button to adjust the angle of central / mid section of the table. With this, it is possible to place the table in the Kyphosis and Trendelenburg positions.



Manual functions

- Adjusting the inclination of the «headrest + armrest» ensemble
 - To lower the section, move the lever ① that operates the gaslift and press down until the desired inclination is obtained.
 - To raise the section, move the lever ① that operates the gaslift and follow the section until the desired inclination is obtained.




- Armrest adjustment

- Use both hands to raise the armrest.
- Press inwards as indicated by the arrow ① and move the armrest ② up through the guide to the desired position.




- To raise the armrest, press lightly in the direction indicated by the arrow (applying pressure to the spring) and then guide it upwards until it is correctly fixed in a horizontal position.




- Armrest adjustment

- Use both hands to lower the armrest.
- Press inwards as indicated by the arrow ① and move the armrest ② down the guide to the desired position




INSTRUCTIONS FOR ASSEMBLY (option part)

Place the paper roll holder in the position indicated in the image below. Tighten the 2 locking knobs until secure.
















- Side armrest adjustment

- To fold the armrest, press lightly in the direction indicated by the arrow (applying pressure to the spring) and then push it downwards.



Legend to symbols and information on the product label.

- **Model:** Product identification.
- **Model Num.:** Product version.
-  : CE conformity marking.
-  : Medical Device
-  : Unique serial number identifying the product.
-  : Date of manufacture.
- **Product Net Weight :** Table weight in kg.
- **INPUT :** Necessary values of the electrical mains supply.
- **ON: 2 min / OFF: 18 min:** Indicates the discontinuous operation of the device according to IEC/EN 60601-1, which indicates that 2 minutes of continuous operation of the motor or motors should not be exceeded.
-  : Consult the instructions for use or the user guide.
-  : Maximal load capacity that the table can support.
-  : Maximum patient weight.
-  : Waste from Electrical and Electronic Equipment. Selective waste collection of electrical and electronic equipment is required.
-  : Classification of medical electrical equipment - Double Insulation.
-  : Electrical Safety Classification - Type B.
- **IPX4 :** Protection against splashing water or liquids.
-  : Manufacturer identification.
-  : Authorized representative in the EU.
-  : Importer.

TROUBLESHOOTING

If, during the life of the table you detect any malfunction or need a repair, contact your dealer and do not use the table until you have received a diagnosis or the table has been professionally repaired.

MAINTENANCE

Carry out a visual inspection at least once a month to check the general conditions of the table. Moreover, you must do the following:

- Check the correct adjustment of the different sections.
- Check the proper functioning of the motors and their movements.

- Check and clean the gas struts
- Check and tighten screws (if necessary).
- Grease the parts with friction.
- Check the conditions of the electrical wiring and the socket.
- Check the wheel immobilization system.

RECYCLING

If you need to dispose of the table or any of its parts or accessories, consult and respect the laws and regulations applicable to waste management and protection of the environment.

WARRANTY

This warranty shall remain in effect for 5 years (60 months) for the structure and 3 years (36 months) for the base frame and motor from the date of original consumer purchase. An original sales receipt or proof of purchase may be required in order to redeem the warranty.

All repairs to the Product must be performed by a service center certified by CoinfyCare. Any modifications or repairs performed by unauthorized centers or groups will void this warranty. This statement of guarantee prevails over any other statement specified or implied by the seller.

CLEANING AND DISINFECTION

Before cleaning the table, unplug it from the mains. Clean the table after each use.

Disinfect the table with a soft, dry cloth.

To clean the upholstery, apply a solution of warm water and a mild detergent (for example, neutral soap) with a well wrung soft cloth. Wipe the table over once cleaned.

Disinfect upholstery and other surfaces with a suitable bactericide for this purpose.

Apply the disinfectant on a soft cloth, never directly on the table.

Never use a mixture of disinfectants or a mixture of disinfectant and soap.

Wipe the table upholstery over once cleaned & disinfected with a cloth and water only. This will remove any residue from the upholstery.

Avoid the accumulation of moisture on the parts of the metal structure, as they could rust.

Since we do not know which disinfectant will be used, we cannot guarantee that it will not cause damage to the upholstery. Read the instructions and warnings for use of the disinfectant product carefully before its purchase or use.

TRANSPORTATION AND STORAGE CONDITION

Transport condition

The products can be transported by general means of transportation. They should be protected from the sun and rain, and should not be mixed with toxic, harmful and corrosive materials.

Storage

The packed electric multifunctional physiotherapy bed should be stored in a dry and well ventilated environment without corrosive gas.

This table should be operated, transported, and stored in temperatures between -10° C to + 50° C, with max humidity of 95%.

SHUTDOWN PROCEDURE

Adjust the bed to a suitable position to ensure that the patient is safely left, then turn off the power.

Contraindication

Please note that our beds are not sterilized. Please do not use them according to aseptic standards.

CONTACT

Applicant / company name / after sales service unit:

Huangshan Jinfu Medical Equipment Co., Ltd
Domicile / production address: No. 17,
Qiliting, Qimen County, Huangshan City,
Anhui Province China
Tel: 0086 571 87006218
www.coinfyicare.com


EC	REP
----	-----



European legal representative:

LOTUS NL B.V.


Koningin Julianaplein 10, 1e Verd 2595AA,
The Hague, Netherlands



EL01PRO23





No. of sections	1
Side rails	✓
No. of motors	1 (height)
Height adjustment	Peripheral foot bar / foot switch
 / SWL	68 kg / 250 kg
	5 cm 36 kg/m³
Upholstery	MED PVC



EL02PRO23





No. of sections	2
Armrests	✗
No. of motors	1 (height)
Height adjustment	Peripheral foot bar / foot switch
 / SWL	68 kg / 250 kg
	5 cm 36 kg/m³
Upholstery	MED PVC



EL022PRO23





No. of sections	2
Armrests	✓
No. of motors	1 (height)
Height adjustment	Peripheral foot bar / foot switch
 / SWL	70 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC



EL022ARPRO23





No. of sections	2
Armrests	✓
No. of motors	1 (height)
Height adjustment	Peripheral foot bar / foot switch
 / SWL	71 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC



EL03PRO23




No. of sections	3
Armrests	✗
No. of motors	1 (height)
Height adjustment	Peripheral foot bar / foot switch
 / SWL	72 kg / 250 kg
	5 cm 36 kg/m³
Upholstery	MED PVC



EL03EPRO23




No. of sections	3
Armrests	✗
No. of motors	1 (height)
Height adjustment	Peripheral foot bar / foot switch
 / SWL	71 kg / 250 kg
	5 cm 36 kg/m³
Upholstery	MED PVC



EL032PRO23




No. of sections	3
Armrests	✓
No. of motors	1 (height)
Height adjustment	Peripheral foot bar / foot switch
 / SWL	73 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC

EL04PRO23







No. of sections	4
Armrests	✗
No. of motors	1 (height)
Height adjustment	Peripheral foot bar / foot switch
 / SWL	88 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC

EL05PRO23







EL05ARPRO23





No. of sections	3	
Armrests	EL05PRO ✓	EL05ARPRO ✓ Standard+ laterals
No. of motors	2 (height + Central sections)	
Height adjustment	Peripheral foot bar / foot switch	
Adjustment of the central section	Button control	
 / SWL	EL05PRO23 88 kg / 250 kg	EL05ARPRO23 92 kg / 250 kg
	5 cm 36 kg/m ²	
Upholstery	MED PVC	
Positions	Trendelenburg and Kyphosis	



EL052PRO23





No. of sections	3
Armrests	✓ Standard+ wing armrests
No. of motors	2 (height + Central sections)
Height adjustment	Peripheral foot bar / foot switch
Adjustment of the central section	Button control
 / SWL	88 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC
Positions	Trendelenburg and Kyphosis



EL11PRO23




No. of sections	1
Armrests	✓
No. of motors	1 (height)
Height adjustment	Peripheral foot bar / foot switch
 / SWL	65 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC

EL11ARPRO23



No. of sections	1
Armrests	✓
No. of motors	1 (height)
Height adjustment	Peripheral foot bar / foot switch
 / SWL	68 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC



**EL01PRO29 / EL11PRO29 / EL11ARPRO29 /
EL02PRO29 / EL022PRO29 / EL022ARPRO29 /
EL03PRO29 / EL03EPRO29 / EL032PRO29**

Hydraulic Treatment Table

USER GUIDE

SAFETY PRECAUTIONS

1. During the adjustment of the table, do not put any part of the body into the gap of any moving parts.
2. Please operate with both hands when adjusting the leaning angle of back, foot or head sections.
3. When the patient is on the table, it is not recommended to adjust the angle of the table top.
4. Before using the product, ensure the four feet of the table frame touch the ground at the same time and check the stability of the table frame.
5. A regular inspection (at least once a year) is needed for the treatment table.
6. Do not exceed the table weight capacity of 250 kg. The safe working load of the arm rest is 15 kg.
7. Always clean the table after each use with a soft cloth dampened with water and a mild antibacterial detergent. Do not use abrasive cleaners.
8. Please DO NOT make any changes to the table. Replacement parts or labor can be provided by Coinfyicare, the selling dealer or a service technician certified by the manufacturer.

CONTENTS OF CARTON

Hydraulic Treatment Table: 1 unit
User Guide: 1 unit

NORMAL OPERATING CONDITIONS

Temperature: 0 °C - 40 °C
Relative humidity: 10% - 95%
Air pressure range: 860hpa-1060hpa

REGULATION AND PRODUCT STANDARDS

This table complies with the European regulation of medical devices (EU) 2017/745 and with the following standards:

- EN ISO 13485:2016
Medical devices - Quality management systems - Requirements for regulatory purposes (ISO 13485:2016)
- DIN EN ISO 13485:2016

PRECAUTIONS AND SAFETY INDICATIONS

Coinfyicare is not liable for any material or personal damage due to misuse or incorrect use of this table or for any purpose other than described in this user guide.

Inspect the condition of the table before using it for the first time and on a recurring basis as indicated in the "MAINTENANCE" section.

Keep table out of high moisture environments.

Do not transport the table over rough or outdoor surfaces. The retractable caster system could become damaged and inoperable.

This table should be operated, transported, and stored in temperatures between -10° C to + 50° C, with max humidity of 95%.

The table should be kept out of the reach of children when there is no adult supervision.

Always use original accessories and spare parts provided by your local dealer.

Always cover the table with a towel, disposable paper or a cover and change it for each user, thus ensuring correct hygiene and extending the useful life of the upholstery.

Only connect the table to a properly installed and grounded outlet. The local mains voltage must correspond to the technical data of the device.

If you detect any abnormality in the operation of the table, consult your dealer or a specialized technician.

Never place your hands or any other part of your body in any hole or void on the table while it is in operation.

Make sure there are no objects in the space under the table that could cause collisions or entrapment during operation.

Make sure that your feet are not resting on the peripheral foot bar or foot control during treatment and especially when sitting near the table. This could create a dangerous situation where your leg is caught between the section and the peripheral foot bar or floor surface.

Take into account the weight distribution on the table when working. The weight must be distributed along the table without concentrating on its ends to maintain the correct stability.

You should not sit on the head and foot sections. If you do, there is a danger of tipping and table damage.

PLACEMENT IN THE WORKPLACE

The table has four castors to facilitate movement to the place where it will be used.

Installation and use instructions:

Moving and adjusting the table

The casters are controlled by a control rod on the table frame.

- Push the control rod down (it is recommended to use your feet to push) to activate the casters. When the casters are on the ground the table is in a moving status.(Figure 1)
- Push the control rod up (it is recommended to use your feet) and the casters are in the retracted status. When the casters are retracted the table is in a fixed position.




Figure 1 Control rod

- Adjustable feet for height adjustment are installed on two legs of the table. Every time after moving, please make sure that the four adjustable feet are in full contact with the ground, otherwise you should rotate the adjustable feet to adjust.(Figure 2)




Figure 2 Adjustable feet of the table

Please confirm the table is in a fixed position before treating the patient. It is strictly forbidden to use a table in "moving status". The "moving status" can only be used when moving the table from place to place.

Every time after moving, please make sure that the four adjustable feet are in full contact with the ground, otherwise you should rotate the adjustable feet to adjust.

After using the device, please make sure the table in its lowest level position, and adjust the head/waist/tail sections to its flat position.

Lifting the table

Control lever under the table is for height adjustment. (Figure 3)




Figure 3




Figure 4

Before operation, please confirm that there are no objects in the space under the table.(Figure 4)

In order to reduce the risk of injury caused by the patient rolling off the table when unattended, the table should be placed at the lowest level.

Manual functions

Adjusting the angle of the head section

As shown in the Figure 5, pull the control lever (in the direction shown by the arrow) to adjust the horizontal angle of the head section.




Figure 5

Adjusting the angle of the bed tail section

- As shown in the Figure 6, pull the control lever (in the direction shown by the arrow) to adjust the angle of the bed tail section.
- When the desired angle is reached, release the control lever and the bed tail section angle will be locked.






Figure 6

- Armrest adjustment

- Use both hands to raise the armrest.
- Press inwards as indicated by the arrow ① and move the armrest ② up through the guide to the desired position.




- To raise the armrest, press lightly in the direction indicated by the arrow (applying pressure to the spring) and then guide it upwards until it is correctly fixed in a horizontal position.




- Armrest adjustment

- Use both hands to lower the armrest.
- Press inwards as indicated by the arrow ① and move the armrest ② down the guide to the desired position




INSTRUCTIONS FOR ASSEMBLY (option part)

Place the paper roll holder in the position indicated in the image below. Tighten the 2 locking knobs until secure.












- Side armrest adjustment

- To fold the armrest, press lightly in the direction indicated by the arrow (applying pressure to the spring) and then push it downwards.



Legend to symbols and information on the product label.

- **Model:** Product identification.
- **Model Num.:** Product version.
-  : CE conformity marking.
-  : Unique serial number identifying the product.
-  : Date of manufacture.
- **Product Net Weight :** Table weight in kg.
-  : Consult the instructions for use or the user guide.
-  : Maximal load capacity that the table can support.
-  : Maximum patient weight.
-  : Manufacturer identification.
-  : Authorized representative in the EU.
-  : Importer.

TROUBLESHOOTING

If, during the life of the table you detect any malfunction or need a repair, contact your dealer and do not use the table until you have received a diagnosis or the table has been professionally repaired.

MAINTENANCE

Carry out a visual inspection at least once a month to check the general conditions of the table. Moreover, you must do the following:

- Check the correct adjustment of the different sections.
- Check and clean the hydraulic pod.
- Check and tighten screws (if necessary).
- Grease the parts with friction.
- Check the wheel immobilization system.

RECYCLING

If you need to dispose of the table or any of its parts or accessories, consult and respect the laws and regulations applicable to waste management and protection of the environment.

WARRANTY

This warranty shall remain in effect for 5 years (60 months) for the structure and 1.5 years (18 months) for the base frame and Hydraumatic from the date of original consumer purchase. An original sales receipt or proof of purchase may be required in order to redeem the warranty. All repairs to the Product must be performed by a service center certified by CoinfyCare. Any modifications or repairs performed by unauthorized centers or groups will void this warranty. This statement of guarantee prevails over any other statement specified or implied by the seller.

CLEANING AND DISINFECTION

Before cleaning the table, unplug it from the mains. Clean the table after each use.

Dust the table with a soft, dry cloth.

To clean the upholstery, apply a solution of warm water and a mild detergent (for example, neutral soap) with a well wrung soft cloth. Wipe the table over once cleaned.

Disinfect upholstery and other surfaces with a suitable bactericide for this purpose.

Apply the disinfectant on a soft cloth, never directly on the table.

Never use a mixture of disinfectants or a mixture of disinfectant and soap.

Wipe the table upholstery over once cleaned & disinfected with a cloth and water only. This will remove any residue from the upholstery.

Avoid the accumulation of moisture on the moving parts of the metal structure, as they could rust.

Since we do not know which disinfectant will be used, we cannot guarantee that it will not cause damage to the upholstery. Read the instructions and warnings for use of the disinfectant product carefully before its purchase or use.

TRANSPORTATION AND STORAGE CONDITION

Transport condition

The products can be transported by general means of transportation. They should be protected from the sun and rain, and should not be mixed with toxic, harmful and corrosive materials.

Storage

The packed electric multifunctional physiotherapy bed should be stored in a dry and well ventilated environment without corrosive gas.

This table should be operated, transported, and stored in temperatures between -10° C to + 50° C, with max humidity of 95%.

SHUTDOWN PROCEDURE

Adjust the bed to a suitable position to ensure that the patient is safely left, then turn off the power.

Contraindication

Please note that our beds are not sterilized.
Please do not use them according to aseptic standards.

CONTACT

Applicant / company name / after sales service unit:


Huangshan Jinfu Medical Equipment Co., Ltd
Domicile / production address: No. 17,
Qiliting, Qimen County, Huangshan City,
Anhui Province China
Tel: 0086 571 87006218
www.coinfyicare.com



EC	REP
----	-----

European legal representative:
LOTUS NL B.V.


Koningin Julianaplein 10, 1e Verd 2595AA,
The Hague, Netherlands



EL01PRO29




No. of sections	1
Armrests	✗
No. of motors	✗
Height adjustment	Control lever (hydraulic)
 / SWL	70 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC



EL11PRO29




No. of sections	1
Armrests	✓
No. of motors	✗
Height adjustment	Control lever (hydraulic)
 / SWL	70 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC



EL11ARPRO29




No. of sections	1
Armrests	✓
No. of motors	1 (height)
Height adjustment	Control lever (hydraulic)
 / SWL	72 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC



EL02PRO29




No. of sections	2
Armrests	✗
No. of motors	✗
Height adjustment	Control lever (hydraulic)
 / SWL	70 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC



EL022PRO29





No. of sections	2
Armrests	✓
No. of motors	1 (height)
Height adjustment	Control lever (hydraulic)
 / SWL	69 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC



EL022ARPRO29





No. of sections	2
Armrests	✓
No. of motors	1 (height)
Height adjustment	Control lever (hydraulic)
 / SWL	70 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC



EL03PRO29




No. of sections	3
Armrests	✗
No. of motors	1 (height)
Height adjustment	Control lever (hydraulic)
 / SWL	67 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC



EL03EPRO29



No. of sections	3
Armrests	✗
No. of motors	1 (height)
Height adjustment	Control lever (hydraulic)
 / SWL	67 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC

EL032PRO29



No. of sections	3
Armrests	✓
No. of motors	1 (height)
Height adjustment	Control lever (hydraulic)
 / SWL	74 kg / 250 kg
	5 cm 36 kg/m ³
Upholstery	MED PVC

CONFY CARE[®]